



HOW TO INSTALL INSPIRE POLYELITE V2 LED TAPE LIGHT

Step 1: Measure Area for LED Tape Light

Use a measuring tape to measure each of the areas you want to put *Inspire* PolyElite V2 LED Tape Light.

Step 2: Select Correct Driver Size

Use this simple calculation to figure out how large of a driver you need to use:

Run Length	x	Tape Light Wattage (per foot)	=	Total Watts
Measured in step 1		Inspire PolyElite V2 BRIGHT LED Tape Light is 3.5 watts/FT Inspire PolyElite V2 SUPER BRIGHT LED Tape Light is 4.7 watts/FT		Correct driver must be able to power at least this amount of watts
Example: (25 Foot Run Length) x (Inspire V2 BRIGHT LED Tape Light (3.5 watts/foot)) = 87.5 Watts You need a driver that can power at least: 87.5 Watts.				


Step 3: Make Sure to Stay Within the Max Run Length Limits

There is a maximum amount of feet of *Inspire* PolyElite V2 LED Tape Light that can be plugged into together in one continuous run. **DO NOT** exceed the maximum run length limits. You will void the warranty and possibly damage the tape light.

Inspire PolyElite V2 BRIGHT LED Tape Light	28 Foot Max Run Length
Inspire PolyElite V2 SUPER BRIGHT LED Tape Light	21 Foot Max Run Length

NOTE: You can power more than one run of LED tape light by wiring multiple hardwire connectors (#CON-HW) into the same driver.

Step 4: Connect Everything Together - Sample Wiring Diagram



Optional: Cut the *Inspire* PolyElite V2 LED Tape Light

You can cut the *Inspire* PolyElite V2 LED Tape Light only on the cut marks. See the example below:



NOTE: Once you cut the polyurethane coated *Inspire* PolyElite V2 LED Tape Light you cannot re-attach more tape light to continue your run.